

- . Plumbing fixtures and grab bars are meant to be centered between the tiles on the grout lines. Tiler may move fixtures as needed.
- 2. One tile to be drilled on Left wall for the upper control valve.
- 3. Dimensions shown are based on the subfloor and rough framing. Values may changed once shower base is installed.
- 4. Shelves are to be centered between tiles in grout area, except on Left wall one tile to be split between other 2 shelves.

Daltile -

- 1. Left and Right side walls pattern starts with full tiles on side walls at the bottom back of shower.
- 2. Entrance wall starts with tiles same vertical height as side walls with the tiles centered on wall horizontally.
- 3. Flat tiles to be placed inside window and door.

Cavallo Arabesque -

1. Back wall - pattern starts with full tiles at bottom of window and centered on the wall horizontally.

Master Shower Tile Layout Elevation View